

**IT3441**

**100%**

**Position**


**Print size (mm)**

**Print code (no of colors)**

1: Top  
2: Top

ø25  
ø31

P2(4)/B  
DO(8)/B



**Note: Logo or text is readable when the purse holder is being used.**